



Rehydrate Master Mix



Step 1

Rehydrate lyophilized Multiplex Master Mix with 40 µl molecular grade water.


Add Sample



Step 2

Transfer 10 µl rehydrated Master Mix to 4 empty tubes. Add 5 µl purified nucleic acid.

Run PCR



Step 3

Close tubes, pulse spin and load to real-time PCR instrument. Start PCR run.